



Figure 2: TF01-01 OIL TANK ASSY.

IPBTF01-01 - OIL TANK ASSEMBLY PARTS LIST
IPBTF01-01 (SH. 1 of 2)

KEY NO.	PART NO.	DESCRIPTION	QTY.
1	1011	OIL TANK SUPPORT	1
2	1001	OIL TANK COVER	2
3	1002	OIL TANK	2
4	1003	OIL TANK BOTTOM	2
5	1006	STOP VALVE CYLINDER	2
6	1005	STOP VALVE CAP	2
7	1009	STOP PISTON ASSEMBLY	2
8	1010	DIFFUSER PLATE	2
9	P0004	U-CUP SEAL	2
10	P0005	BARB FITTING	2
11	P0039	O-RING	4
12	P0040	COMPRESSION SPRING	2
13	P0041	O-RING	2
14	P0046	CONNECTOR ½ TUBE X ¼ NPT	2
15	P0050	HARDENED WASHER	4
16	P0118	ELBOW MALE 1/8 NPT x ¼ TUBE	2
17	P0166	O-RING	4
18	P0169	(SQUEEGEE MOTION) DECAL	2
19	P0208	O-RING	2
20	P0241	O-RING	2
21	P0716	FLOW CONTROL VALVE	2
22	P0717	ELBOW MALE ¼ NPT x ¼ NPT	2
23		#8 FLAT WASHER	4
24		#8 SPLIT LOCK WASHER	4

**OIL TANK ASSEMBLY
IPBTF01-01 (SH. 2 of 2)**

KEY NO.	PART NO.	DESCRIPTION	QTY.
25		8-32 X 5/8" SHCS	4
26		6-32 X 3/8" SHCS	4