



Figure 4: TF01-03 SQUEEGEE CARRIAGE ASSY

IPBTF01-03 SQUEEGEE CARRIAGE ASSEMBLY PARTS LIST
IPBTF01-03

KEY NO.	PART NO.	DESCRIPTION	QTY.
1	1U07	SQUEEGEE CARRIAGE	1
2	1U09	PISTON ROD SLEEVE	1
3	1U10	SPRING CUP	1
4	1U16	SWITCH ACTIVATOR	1
5	1U23	THUMB SCREW SPACER	2
6	1X10	LOCK ASSEMBLY	2
7	P0016	THUMB SCREW KNOB	7
8	P0030	STEEL BALL DIA 3/16"	1
9	P0032	COMPRESSION SPRING	1
10	P0038	BELLEVILLE WASHER	2
11	P0050	HARDENED WASHER	2
12	P0157	LINEAR BEARING	4
13	P0158	DUST SEAL	4
14	P0159	COMPRESSION SPRING	2
15		10-32 X 1-1/2" SET SCREW	2
16		1/4-20 X 1" SET SCREW	1
17		3/16" X 1" DOWEL PIN	1
18		1/8" X 1-1/4" DOWEL PIN	2
19		10-32 X 1/4" BHS	2
20		10-32 X 1" SHCS	2
21		8-32 X 7/8" SHCS	2
22		1/4-20 X 5/8" SHCS	1